



Franz Video Equipment  
 Schulhof 4  
 97286 Winterhausen-  
 GERMANY

**Infrarotset AXIS 2xx Serie**

Das Infrarotset Axis 2xx ermöglicht Ihnen Aufnahmen bei völliger Dunkelheit. Um die Kamera nachtsichttauglich zu machen, wurde diese mit einem Spezialobjektiv Ausgerüstet. Dadurch ist nur eine S/W Bildwiedergabe möglich.  
 .An der Gehäuserückseite können Sie die gewünschte Lichtstärke einstellen. Bei Nahaufnahmen kann es zu Überstrahlungen kommen. Um dies zu vermeiden können Sie die Lichtleistung stufenlos einstellen.

**Kameraeinstellungen:**

Nach dem Programmstart z.B. IP utility müssen Sie im Menue **VIDEO/IMAGE** unter **ADVANCED** den **COLOURLEVEL** auf **0** stellen.

Bitte vergessen Sie nicht das Abspeichern.

Um den Scheinwerfer Ein/Ausschalten zu können, müssen Sie den **I/O Port** der Kamera konfigurieren.

Im Menue **Liveview setup** aktivieren Sie den Schalter **SHOW MAN.TRIGGER**.

Danach **OUTPUT 1** auf **ACTIVE/INACTIVE**.

Bitte vergessen Sie nicht das Abspeichern.

**Anschluß Relaisplatine an die Kamera**

Um den Scheinwerfer schalten zu können , müssen sie die Anschlußkabel mit dem I/O Port der Kamera Verbinden. Die Anschlußfolge des grünen Anschlußsteckers ist im Usermanual der Kamera beschrieben.

**VORSICHT! Die Axis 207 und 207W haben verschiedene Anschlüsse!**

	<b>AXIS 207</b>	<b>AXIS 207W</b>
<b>Rotes Kabel</b>	<b>Pin 1</b>	<b>Pin 2</b>
<b>Schwarzes Kabel</b>	<b>Pin 4</b>	<b>Pin 4</b>

**Infraredset Axis 2xx series**

The Infraredset for AXIS 2xx series allows you sharp and noiceless pictures in 0-Lux conditions. To make the camera work for this , you have to replace the original optic with the special optic which is in the kit.

On the housingbackside you can adjust the lightoutput .

**Camera adjustments:**

After you start the camera with the IP-utility program please got to **SETUP** and choose **VIDEO&IMAGE**. Klick to **ADVANCED** There you put the **colourlevel** to **0**

To switch the Infrared illuminator **ON /OFF** over IP you have to do some settings in the camera menue:

Choose the menue **LIVEVIEW SETUP**. Activate the bottom **SHOW MANUAL TRIGGER**.

Below this you find **OUTPUT 1**: there you adjust **ACTIVE /INACTIVE**

**Don´t forget to push SAVE after the adjustments.**

Back to the livepicture you can the the manual bottom over the picture. To make the bottom work it is a need to connect the lightsource to the I/O port on the backside from the camera.

Please have a look at the camera manual to see in which position you can find each PIN.

**ATTENTION! The 207 and 207W modell have different Pins**

	<b>AXIS 207</b>	<b>AXIS 207W</b>
<b>Red cable</b>	<b>Pin 1</b>	<b>Pin 2</b>
<b>Balck cable</b>	<b>Pin4</b>	<b>Pin 4</b>